


HM126 PORTABLE SAWMILL

9.5 and 14 Horsepower Models



OPERATOR'S MANUAL



This page intentionally left blank.



TABLE OF CONTENTS

TABLE OF CONTENTS	1
INTRODUCTION	3
INTENDED USE	3
SAFETY GUIDELINES	4
WORK AREA	5
INTERNAL COMBUSTION ENGINE SAFETY	5
PERSONAL SAFETY	6
TOOL USE AND CARE	7
EQUIPMENT OPERATION	8
MAINTENANCE	9
TECHNICAL SPECIFICATIONS	10
OVERALL DIMENSIONS	11
ASSEMBLY	12
1. TOOLS REQUIRED	12
2. UNPACKING	13
3. TRACK	14
4. LOG CLAMP AND SUPPORTS	18
5. SAWMILL HEAD ASSEMBLY	21
FRONT POSTS	21
CARRIAGE LEGS	22
REAR POSTS	24
CROSS BEAM	25
LUBRICATION TANK	27
DASHBOARD	28
LIFT MECHANISM	29
LIFT CABLE ROUTING	30
PUSH HANDLE	32
LUBRICATION TUBING	33
LOG SCALE	35
TIGHTEN CARRIAGE WHEEL BOLTS	36
6. PLACING THE HEAD ON THE TRACK	37
METHOD 1	38
METHOD 2	39
DIRECTION OF CUT	40



LEVELLING THE SAWMILL HEAD ASSEMBLY _____	41
THROTTLE HANDLE AND CABLE _____	42
GREASING THREADS _____	45
BAND WHEEL DOOR LATCHES _____	46
ROLLING THE SAWMILL HEAD ASSEMBLY _____	47
7. ENGINE _____	48
ENGINE OIL _____	48
SAWMILL SET-UP PROCEDURES _____	49
BELT TENSION _____	49
BLADE TRACKING _____	51
BLADE GUIDE ADJUSTMENT _____	55
SAWMILL MAINTENANCE _____	57
BLADE TENSION _____	57
CHANGING THE BLADE _____	57
REPLACING BELTS _____	58
TROUBLESHOOTING _____	60
REPLACEMENT PARTS ORDERING _____	61
PARTS LIST _____	62
EXPLODED ASSEMBLY VIEWS _____	66
TRACK _____	66
SAW HEAD _____	67
BACK BEAM _____	68
GUIDE BLOCK HOLDERS _____	69
BAND WHEEL HOUSING _____	70
BAND WHEEL HOUSING DOORS _____	71
BAND WHEELS AND IDLER _____	72
ENGINE COMPONENTS—14 hp _____	73
ENGINE COMPONENTS—9.5 hp _____	74
CARRIAGE _____	75
CARRIAGE LEG, WHEEL, AND SWEEPER _____	76
LIFT MECHANISM _____	77
THROTTLE HANDLE _____	78
TUBING & CABLES _____	79
NOTES _____	80



INTRODUCTION

Congratulations on your purchase and welcome to Woodland Mills! This manual gives you the necessary information about your machine so you will be able to use it properly. The entire manual must be read and understood before you start using the machine. If any questions should arise that are not covered by this manual, please contact Woodland Mills Inc.

OWNER'S RECORD

Please take a moment to record the following information about your sawmill. If you need to call for assistance, please be ready to provide your model and serial numbers. This information will allow us to help you more quickly when you call.

MODEL NUMBER

SERIAL NUMBER

DATE OF PURCHASE

This machine is designed for certain applications only. We strongly recommend that this machine is not modified and/or used for any application other than that for which it was designed. If you have any questions relative to a particular application, DO NOT use the machine until you have first contacted us to determine if it can or should be performed on the product.

For technical questions and replacement parts, please contact Woodland Mills Inc.

INTENDED USE

Woodland Mills wood sawmills are designed for acreage owners to aid in the milling of natural, untreated wood with the mill firmly supported on the ground. Materials that are processed may contain chemicals or by-products that could corrode the machine or damage it, resulting in safety concerns.



SAFETY GUIDELINES

****SAVE THESE INSTRUCTIONS****



WARNING!

Read and understand all instructions. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.



WARNING!

The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions or situations that could occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product but must be supplied by the operator.



WARNING!

Only operate the engine in a well ventilated area. Carbon Monoxide (CO) produced by the engine during use can kill. Do not use indoors, near windows, or in other sheltered areas.

NOTE: All Federal and State laws and any regulation having jurisdiction covering the safety requirements for use of the machine take precedence over the statements in this manual. Users of this machine must adhere to such regulations.



WORK AREA

- **Keep work area clean, free of clutter and well lit.** Cluttered and dark work areas can cause accidents.
- **Do not use your sawmill where there is a risk of causing a fire or an explosion;** e.g. in the presence of flammable liquids, gasses, or dust. Power tools create sparks which may ignite the dust or fumes.
- **Keep children and bystanders away** while operating a power tool. Distractions can cause you to lose control, therefore, visitors should remain a safe distance from the work area.
- **Be aware of all power lines,** electrical circuits, water pipes and other mechanical hazards in your work area, particularly those hazards below the work surface hidden from the operator's view that may be unintentionally contacted and cause personal harm or property damage.
- **Be alert of your surroundings.** Using power tools in confined work areas may put you dangerously close to cutting tools and rotating parts.

INTERNAL COMBUSTION ENGINE SAFETY

WARNING!

Internal combustion engines present special hazards during operation and fuelling. Read and follow the warning instructions in the engine Owner's Manual and the safety guidelines below. Failure to follow the warnings and safety standards could result in severe injury or death.



- **DO NOT** run the machine indoors or in an enclosed area such as a deep trench unless adequate ventilation, through such items as exhaust fans or hoses, is provided. Exhaust gas from the engine contains poisonous carbon monoxide gas (CO); exposure to carbon monoxide can cause loss of consciousness and may lead to death.
- **DO NOT** smoke while operating the machine.
- **DO NOT** smoke when refuelling the engine.
- **DO NOT** refuel a hot or running engine.
- **DO NOT** refuel the engine near an open flame.
- **DO NOT** spill fuel when refuelling the engine.
- **DO NOT** run the engine near an open flame.
- **ALWAYS** refill the fuel tank in a well-ventilated area.
- **ALWAYS** replace the fuel tank cap after refuelling.
- **ALWAYS** check the fuel lines and the fuel tank for leaks and cracks before starting the engine. Do not run the machine if fuel leaks are present or the fuel lines are loose.
- **ALWAYS** avoid contact with hot fuel, oil, and exhaust fumes.



PERSONAL SAFETY

- **Stay alert, watch what you are doing and use common sense when operating a power tool.** Do not use a power tool when you are tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating power tools may result in serious personal injury.
- **Dress properly.** Do not wear loose clothing, dangling objects, or jewelry. Keep your hair, clothing, and gloves away from moving parts. Loose clothes, jewelry, or long hair can be caught in moving parts. Air vents often cover moving parts and should be avoided.
- **Use safety apparel and equipment.** Use safety goggles or safety glasses with side shields which comply with current national standards, or when needed, a face shield. Use a dust mask in dusty work conditions. This applies to all persons in the work area. Also use non-skid safety shoes, hardhat, gloves, dust collection systems, and hearing protection when appropriate.
- **Do not overreach.** Keep proper footing and balance at all times.
- **Remove adjusting keys or wrenches** before connecting to the power supply or turning on the tool. A wrench or key that is left attached to a rotating part of the tool may result in personal injury.
- **Never make blade guide adjustments, remove or install blades, or conduct any other maintenance or make any other adjustments while the engine is running.** Always shut the engine off, remove the ignition key, and turn the engine off before carrying out any of the aforementioned procedures. Consult your engine manual for safe shutdown procedures to prevent accidental ignition.



TOOL USE AND CARE

- **Always** be sure the operator is familiar with proper safety precautions and operation techniques before using machine.
- **Never touch** the engine or muffler while the engine is on or immediately after it has been turned off. These areas get extremely hot and can cause burns.
- **Always** close the fuel valve on the engine when the machine is not in use.
- **Do not force the tool.** Tools do a better and safer job when used in the manner for which they are designed.
- **Never use the sawmill** with a malfunctioning switch or throttle. Any power tool that cannot be controlled with the switch is dangerous and must be repaired before using.
- Turn off the engine and place the switch in the locked or off position before servicing, adjusting, installing accessories or attachments, or storing. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- Secure logs with the log screw clamping device instead of with your hand or another individual's help. This safety precaution allows for proper tool operation using both hands.
- **Storing sawmill.** When the sawmill is not in use, store it in a dry, secure place or keep well covered and out of the reach of children. Inspect the sawmill for good working condition prior to storage and before re-use.
- **Maintain your sawmill.** It is recommended that the general condition of the sawmill be examined before it is used. Keep your sawmill in good repair by adopting a program of conscientious repair and maintenance in accordance with the recommended procedures found in this manual. If any abnormal vibrations or noise occurs, turn the sawmill off immediately and have the problem corrected before further use.
- **Keep saw blades sharp and clean.** Properly maintained bandsaw blades are less likely to bind and are easier to control.
- **Cleaning and Lubrication.** Use only soap and a damp cloth to clean your sawmill. Many household cleaners are harmful to plastic and rubber components on the sawmill.
- **Use only accessories that are recommended** by the manufacturer for your model. Accessories that may be suitable for another sawmill may create a risk of injury when used on the sawmill.
- **Always** operate machine with all safety devices and guards in place and in working order. DO NOT modify or make changes to safety devices. DO NOT operate machine if any safety devices or guards are missing or inoperative.
- **Never leave sawmill running unattended.**
- **Coiled blades can spring apart with considerable force and unpredictably in any direction.** Always deal with coiled blades, including those packaged in boxes, with the utmost care.
- **Never use the equipment to cut anything other than lumber** or for any purpose other than cutting lumber as described in this manual.



EQUIPMENT OPERATION

1. Wear heavy-duty work gloves, ANSI-approved goggles behind a full face shield, steel-toed work boots, and a dust mask.
2. Operate only with assistance.
3. Cut-off branches from the lumber to be processed.
4. Place the lumber to be cut on the track supports.
5. Clamp the lumber firmly in place using the included log clamps and supports.
6. Fill the lubrication tank with clean water. Add a ¼ cup of liquid dish soap per full tank; add less if topping up a partially full tank. The soap helps keep the blade clean(er) when excess tree oils and sap are encountered.
7. Start and operate the engine according to the provided engine manual.
8. Depress the throttle to bring the blade up to speed—the throttle should be fully depressed while the saw is under load.
9. Roll the head assembly slowly along the track and against the lumber to make the cut.
10. Trim off the rounded sides of the log.
11. When the log is squared-off, boards or posts can be cut to standard or custom specifications.
12. To prevent accidents, turn off the engine and disconnect its spark plug wire after use. Wait for the engine to cool, clean external parts with a clean cloth, then store the equipment out of children's reach.



WARNING!

To avoid death or serious injury, do not cut lumber containing embedded foreign objects such as nails, metal fragments, etc.



WARNING!

The operator and any assistants must stay clear of the front and back of the blade whenever the engine is on.



MAINTENANCE

Proper and routine maintenance is critical to operator safety, achieving good milling results, and to prolong the life of your investment.


- **Band Wheel Bearings** — Inspect before use to ensure they are not worn. Bearings are sealed and do not need to be greased.
- **Blade Guide Bearings** — Inspect before use for excessive grooves or scoring in the bearing case. Replace if necessary.
- **Blade Tension** — Grease threads of tensioning T-handle when dry or as required. Use multi-purpose, extreme-pressure grease.
- **Log Clamps** — Spray the cam mechanism with dry silicone spray frequently.
- **Belts** — Periodically check the condition and wear of the drive and idler belt. Ensure that the blade does not ride on the band wheels.
- **Drive Belt** — Periodically check the tension of the drive belt.
- **Carriage Posts (Front)** — Spray posts before use with a silicone spray lubricant such as 3-in-1 or Jig-A-Loo.
- **Band Wheel Guards** — Routinely remove any build-up of sawdust that may collect inside the band wheel guards.
- **Lubrication Tank** — Only fill with a water and dish soap mixture, or in winter months use windshield washer fluid. Do not leave lubricant in tank if temperature falls below 0° C.
- **Blade Lubricant** — Never use diesel fuel or kerosene as blade lubricant. These substances lead to premature wear of your belts and poor sawing performance. For winter operation, replace the water lubricant with windshield washer fluid.
- **Engine** — Check the engine oil level before each use and maintain the engine per the instructions set out by the engine manufacturer in the engine manual. The engine is equipped with an oil alert system and will not start without adding oil before starting.
- **Lifting Cables** — Before, during, and after operation, regularly inspect the cables for any wear or kinks. Ensure that the cables are in perfect condition. Oil the coiled part of the cable often to prevent premature wear. Replace with new cables as necessary.



TECHNICAL SPECIFICATIONS


The HM126 sawmill comes in two variants: the **HM126-9.5** that utilizes a 9.5 horsepower engine and the **HM126-14** with a 14 horsepower engine. Both versions are assembled and operated in the same manner.

Item	HM126-9.5 Specification	HM126-14 Specification
Gasoline Engine	9.5 hp Kohler Command Pro	14 hp Kohler Command Pro
Max Log Diameter	26" (660 mm)	
Max Board Width	22" (558 mm)	
Max Board Thickness	7" (178 mm)	
Blade Size	1-1/4" x 144" (32 mm x 3657 mm)	
Track Length	153-1/2" (3900 mm)	
Track Width	30-1/2" (775 mm)	
Track Height Adjustability (top of bunk)	7-7/8" to 10-5/8" (200 to 270 mm)	
Product Weight	850 lb (386 kg)	862 lb (391 kg)
Shipping Weight	900 lb (408 kg)	912 lb (414 kg)





OVERALL DIMENSIONS





ASSEMBLY

1. TOOLS REQUIRED


TOOL	SPECIFICATION
Wrench/Socket	7 mm (2X)
Wrench/Socket	10 mm (2X)
Wrench/Socket	13 mm (2X)
Wrench/Socket	14 mm (2X)
Wrench/Socket	15 mm (2X)
Wrench/Socket	16 mm (2X)
Wrench/Socket	17 mm (2X)
Wrench/Socket	18 mm (2X)
Wrench/Socket	19 mm (2X)
Wrench	24 mm or Adjustable Wrench (2X)
Wrench	30 mm or Adjustable Wrench (2X)
Hex Key	3 mm
Hex Key	4 mm
Phillips Head Screwdriver	No. 3
Torque Wrench	Capable of at least 25 ft•lb (34 N•m)
Tape Measure	Standard Inch/Metric Tape Measure

During several of the assembly steps, more than one socket or wrench of the same size may be required to assemble the hardware. A socket or box wrench in combination with an adjustable wrench can be utilized if multiple same size tools are in limited supply.



2. UNPACKING

Unpack the contents of the crate except for the saw head and the two long boxes in the bottom that contain the sections of track. Unfasten the two (2) M8 bolts/nuts on the front of the crate using a socket/wrench. Place two (2) 6-8" (150-200 mm) tall support blocks in front of the crate, bend the front of the crate down, and then lay the cardboard wall over it. Carefully rotate the saw head down onto the cardboard and support blocks and slide it out of the crate as shown below.













The two long track boxes can now be removed and the crate discarded.



3. TRACK


Assemble the track system with the provided components and hardware listed in the table below. It is important to assemble and level the track on a firm foundation before tightening all of the hardware and it should ideally be a minimum of 4" (100 mm) off the ground. This will allow for easy cleanup of sawdust from under the tracks and height adjustment of the log supports.

16x	M10 X 35 mm Flanged Hex Bolt		4x	Track Rail	
28x	M10 X 25 mm Flanged Hex Bolt		2x	Reinforcement Plate	
40x	M10 Flanged Lock Nut		4x	Carriage Stop	
			2x	End Bunk	
			2x	Mid Bunk	
			1x	Centre Bunk*	
			12x	Track Foot	



* Centre bunk incorporates four (4) mounting holes at each end




The track comes completely disassembled from the factory. Lay out all the components on a flat piece of level ground prior to assembly. See the **TRACK** exploded view for a more detailed part breakdown.






When assembling the log bunks to the rails, ensure that the two end bunks are square (90°) as shown in Figure 1. Use sixteen (16) M10 X 25 mm bolts at all end bunk and mid bunk locations (Figures 1 & 2).



Use sixteen (16) M10 X 35 mm bolts to join the centre bunk and reinforcement plates to the rails at the rail joints (Figure 3).




Attach the twelve (12) levelling feet to the track at the locations shown below. The bolt can be turned to either raise or lower the foot to adjust the level of the track (Figure 4). If setting the track on wooden blocks, use wood screws in the four holes to secure each foot in place.



Assemble the four (4) carriage stops to the ends of the rails and tighten the bolts. Ensure carriage stops are assembled to the inside face of the rails, *not* the outside (Figure 5).










The assembled track should measure 30-1/2" (775 mm) wide when measuring from the outside faces of the rails.







4. LOG CLAMP AND SUPPORTS


Assemble the log clamp components as shown below. Attach the completed assembly to the track using four (4) M10 X 25 mm bolts with lock nuts and tighten.

4x	M10 X 25 mm Flanged Hex Bolt		1x	Log Clamp Shaft/Bracket Weldment	
4x	M10 Flanged Lock Nut		1x	Log Clamp Bracket	
			1x	Log Dog Receiver	
			1x	Log Dog	
			2x	Long Log Support	
			2x	Short Log Support	
			4x	T-Handle	




Attach log dog assembly to track as shown below with the four (4) nuts and bolts provided. Note that there are various locations along the track where this assembly can be bolted. Depending on how many track sections are being used, select a log clamp position that will secure the log firmly against the log supports.






Insert log supports into track cross supports and secure with T-handles as shown in the picture below. The T-handle threads should be coated with grease. The sawmill includes two sets of log supports—a short set and a long set. The long set is ideal for large diameter logs while the shorter set is better suited for small logs and square cants.




5. SAWMILL HEAD ASSEMBLY

The sawmill head assembly is built in multiple steps. Follow the sub-sections below using the parts table at the top of each sub-section to gather the necessary components for each step.

FRONT POSTS

2x	Front Post	
----	------------	---





With the saw head resting approximately 6" (150 mm) above the ground, slide the two (2) front posts through the post sleeves. Orient the posts so that the ends with the wider hole spacing are towards the bottom of the assembly. The top ends will be capped in a later step.






CARRIAGE LEGS

The carriage leg sub-assemblies come loosely assembled from the factory. Final tightening of these bolts will be done in a later step. See the ***CARRIAGE LEG, WHEEL, AND SWEEPER*** exploded view for a more detailed part breakdown.


4x	M12 X 80 mm Hex Bolt		4x	M12 Flat Washer	
4x	M12 Lock Nut		2x	Carriage Leg Sub-Assembly	

Using two (2) sockets/wrenches, attach the two (2) carriage leg sub-assemblies to the front posts with four (4) M12 X 80 mm bolts, flat washers, and lock nuts. Be sure the bolts point outward and the carriage wheels are positioned on the inside of the legs. Fully tighten these four (4) M12 bolts so that the plates are firmly attached to the posts. The posts should be pushed all the way up until the carriage leg plates contact the post sleeves.










With the help of another person, stand the saw head upright.






REAR POSTS

Using two (2) sockets/wrenches, attach the rear posts between the carriage leg plates using only one (1) M12 X 80 mm bolt, flat washer, and lock nut per post. Be sure the rear post with the extra holes through the side is assembled on the right-side of the saw head. These extra holes are used to mount the push handle in a later step.

2x	M12 X 80 mm Hex Bolt		1x	Rear Post [Left]	
2x	M12 Lock Nut		1x	Rear Post [Right]*	
2x	M12 Flat Washer				










*Right rear post contains four (4) extra holes for push handle assembly in later step.






CROSS BEAM

With the hardware listed below, assemble the cross beam to the carriage posts.

2x	M12 X 110 mm Hex Bolt		1x	Cross Beam	
7x	M12 X 90 mm Hex Bolt		1x	Log Scale Indicator Bracket	
2x	M12 X 80 mm Hex Bolt		2x	Pulley	
11x	M12 Lock Nut		2x	Spacer [12 mm Lg]	
22x	M12 Flat Washer				

Using two (2) sockets/wrenches and the help of a second person, slide the cross beam over the carriage posts. Use seven (7) M12 X 90 mm bolts and two (2) M12 X 110 mm bolts (with pulleys and spacers) to fasten it in place. Be sure to install the log scale indicator bracket on the right-side behind the pulley. Also take note of the orientation of the two (2) M12 X 110 mm bolts with pulleys and three (3) of the M12 X 90 mm bolts—the bolts are installed pointing outward. Use an M12 flat washer under every bolt head and lock nut.





Finally, install two (2) M12 X 80 mm bolts at the top of each carriage leg. Do *not* fully tighten these bolts at this time.






LUBRICATION TANK

With the hardware listed below, assemble the lubrication tank to the front of the cross beam.








4x	M10 X 25 mm Hex Bolt		1x	Lubrication Tank	
4x	M10 Lock Nut		1x	Lubrication Tank Cap	

Using two (2) sockets/wrenches, assemble the lubrication tank to the cross beam with four (4) M10 X 25 mm bolts and lock nuts. Ensure the bolts point inward.




DASHBOARD

With the hardware listed below, assemble the dashboard to the rear carriage posts.











1x	M12 X 100 mm Hex Bolt		1x	Dashboard	
5x	M12 X 80 mm Hex Bolt		1x	Pulley	
6x	M12 Lock Nut		1x	Spacer [12 mm Lg]	
12x	M12 Flat Washer				

Using two (2) sockets/wrenches, assemble the dashboard to the rear carriage posts with five (5) M12 X 80 mm bolts and one (1) M12 X 100 mm bolt (with pulley and spacer) as illustrated in the picture below. Use an M12 flat washer under every bolt head and lock nut. Do *not* fully tighten these bolts at this time.




LIFT MECHANISM

With the hardware listed below, assemble the lift mechanism to the carriage.



1x	M12 X 120 mm Hex Bolt		4x	M12 Flat Washer	
1x	M12 X 80 mm Hex Bolt		1x	Lift Mechanism Sub-Assembly	
1x	M10 X 25 mm Hex Bolt		2x	Pulley	
2x	M12 Lock Nut		1x	Spacer [12 mm Lg]	
1x	M10 Lock Nut		1x	Spacer [5 mm Lg]	

Using two (2) sockets/wrenches, attach the lift mechanism assembly to the underside of the rear carriage post with one (1) M12 X 120 mm bolt (including the pulleys and 2 spacers—5 mm spacer *between* pulleys), and one (1) M12 X 80 mm bolt as illustrated below. Use an M12 flat washer under each bolt head and lock nut. Then fasten the centre tab to the inside of the dashboard using an M10 X 25 mm bolt and nut. Do *not* fully tighten these bolts at this time.




LIFT CABLE ROUTING

Route the lift cables listed below.


1x	Lift Cable A		1x	Lift Cable B	
----	--------------	---	----	--------------	---

The wire rope lift cables come coiled and both are assembled at one end to the back beam post sleeves. The lengths are specific to each side so do not swap them.


Route lift cable A as shown below. [Dashboard removed from views for clarity.]



Route lift cable B as shown below. [Dashboard and lift cable A removed from view for clarity.]








Be sure to securely tighten the oval chain link with a wrench after the cable loop ends have been attached.







PUSH HANDLE

With the hardware listed below, assemble the push handle to the right rear carriage leg.

4x	M12 X 70 mm Hex Bolt		1x	Push Handle	
4x	M12 Lock Nut		1x	Lubrication Hose Bracket	
3x	M12 Flat Washer				



Attach the push handle to the side of the post using four (4) M12 X 70 mm bolts, three (3) M12 washers, and four (4) M12 lock nuts as shown below. Be sure to attach the nut to the water line bracket without a washer. Fully tighten these bolts.







LUBRICATION TUBING

Use the tubing listed in the table below to complete the routing for the lubrication system.


1x	Tubing: Tank-to-Valve		1x	Tubing: Valve-to-Guide Block	
----	-----------------------	---	----	------------------------------	---

Insert the lubrication tube into the fitting on the tank by simultaneously pushing in the blue collar on the fitting as the tube is inserted. Once inserted, release the blue collar and the tube will be secure. Feed the tube through the bracket as shown below. Attach the other end to the water valve.






Attach the other lubrication tube to the valve on the dashboard and feed it through the water tube bracket located on the right post sleeve and fit it over the end of the copper tube on the guide block.











Insert the lubrication hose as shown below. Use a hex wrench to secure the copper end in position by tightening the set screw so that it lightly pinches the copper tube. Do not over-tighten or the end of the copper tube could be crushed.





LOG SCALE

With the hardware listed below, assemble the log scale components.



2x	M6 X 30 mm Hex Bolt		1x	Log Scale Bracket	
2x	M6 X 25 mm Hex Bolt		1x	Log Scale Indicator	
2x	M6 Lock Nut		1x	Log Scale Rear Indicator Bracket	
6x	M6 Hex Nut		1x	Log Scale Bracket Spacer Plate	

Using two (2) sockets/wrenches, bolt the log scale and spacer plate to the band wheel housing with two (2) M6 X 25 mm bolts and lock nuts as shown below. Attach the log scale rear indicator bracket to the log scale indicator bracket using the M8 threaded knob. Attach the log scale indicator to the log scale rear indicator bracket using two (2) M6 X 30 mm bolts and six (6) M6 nuts as shown below.




TIGHTEN CARRIAGE WHEEL BOLTS

Using two (2) socket/wrenches, tighten the four (4) M20 X 120 mm bolts that fasten the wheels to the carriage leg plates.




6. PLACING THE HEAD ON THE TRACK

Before placing the head on the track, the carriage wheel spacing can be set to ensure they will fit properly on the rails. Check the wheel spacing to ensure that a distance of 30.5" (775 mm) is measured from outside to outside of the wheel grooves as shown below.



To adjust the width of the wheels, washers may be added or removed from each wheel to ensure a distance of 30-1/2" (775 mm) is achieved as shown below.






At this point, most of the sawmill head bolts should only be hand tight. They will be fully tightened when the head is on the track and has settled in to a true and square state. There are two methods in which the sawmill head can be lifted onto the track assembly:

METHOD 1





If a tractor or forklift is available, the head can be lifted onto the track with a lifting strap or chain with a minimum rating of 1000 lb. (450 kg). Attach the lifting strap/chain to the lifting hooks, raise the head up, and rest it on the track so that the grooves in the carriage wheels fit around the track rails. Two people are recommended for this procedure.



METHOD 2

At least two people are required for this method. Start by removing the two (2) carriage stops from one end of the track. The head can be walked over to the track until positioned behind the track as shown below. Once in this position, tilt the head backwards so that the front two wheels are off the ground. Walk the head forward while the grooves in the two front carriage wheels ride along the track rails. Next, using at least two people, lift up on the back of the sawmill head and walk it forward until both rear carriage wheels are seated on the track.

Finally, reattach the two (2) carriage stops to the track rails.




With the sawmill head assembly now resting on the track, tighten all of the bolts.



DIRECTION OF CUT


Always cut in the direction shown below. The log clamp will be to the right side of the log with the log supports on the left. Failure to cut in this direction can cause the log to come loose and possibly cause damage or injury.




****Please follow the instructions in the SAWMILL SET-UP PROCEDURES section. Failure to do so may result in poor sawing performance, damage or injury.****

LEVELLING THE SAWMILL HEAD ASSEMBLY

Using a tape measure, measure the distance from the blade to the top of the log bunk on both the left and right side. The distance should be equal. If the measurements are not equal, adjust the lift cable ends under the lift mechanism sub-assembly to either raise or lower one side.













Using a wrench, turn the nut clockwise to raise one side of the sawmill head assembly, or counter-clockwise to lower it. Double-check the blade height as discussed in the previous step. Once the measurements are equal on both sides, tighten the corresponding jam nut to clamp it securely against tab.





THROTTLE HANDLE AND CABLE


Use the hardware listed below to assemble the throttle handle and route the throttle cable.

1x	M6 X 55 mm Hex Bolt		1x	Throttle Handle	
1x	M6 X 50 mm Hex Bolt		1x	Throttle Cable Bracket	
1x	M4 X 12 mm Phillips Pan Head Screw		1x	Throttle Cable Barrel Clamp	
2x	M6 Lock Nut		1x	Throttle Cable Stop Bushing	
6x	M6 Flat Washer		1x	Throttle Cable	


Install the throttle handle (see next page) *prior* to routing the throttle cable and connecting it to the engine.

Assemble the *throttle cable bracket* to the *inside* of the push handle using one (1) M6 X 50 mm hex bolt, two (2) M6 flat washers, and one (1) M6 lock nut. Install the hardware through the *upper* hole in the push handle and bracket (**Figure 1**).


Next, assemble the throttle handle around the push handle and throttle cable bracket using one (1) M6 X 55 mm hex bolt, four (4) M6 flat washers, and one (1) M6 lock nut. Be sure there is a flat washer (marked with asterisks “*” below) between both of the inside faces of the throttle handle and the push handle/throttle cable bracket (**Figure 2**).



To attach the throttle cable, loosen the M6 hex nut closest to the end of the cable until it is free of the threaded barrel. Pass the unsheathed portion of the cable through the notch in the throttle cable bracket and slide the threaded barrel through the hole in the bracket's flange (**Figure 3**). Before re-tightening the nut, bend the unsheathed portion of the cable to feed it through the slot in the throttle handle, then insert the cable end lug into the hole in the handle (**Figure 4**). Finally, re-thread and tighten the loose nut against the flange in the throttle bracket to secure the cable.




With the throttle lever in the idle position (fully open), slide the *throttle cable stop bushing* over the end of the cable sheath and pull the cable tight at the engine. The sheathed end of the cable should extend past the clamp on the engine (see Figure 2). Next, pass the unsheathed end of the cable through the hole in the barrel clamp and tighten the M4 Phillips pan head screw to secure it in place. This will take the slack out of the cable.




Finally, slide the throttle cable stop bushing along the cable sheath until it stops at the bracket on the engine. Secure it in place by tightening the set screw with a 3 mm hex key.

The assembled throttle handle and routed cable should now match the image below.




GREASING THREADS

Add waterproof grease to the threads of the blade tension T-handle and to the mating washer face prior to use. Proper blade tension is achieved using a torque wrench with a 24 mm socket and torquing the T-handle to 25 ft•lb (34 N•m). See right-side image below.








****Note: It is very important to take the tension off the blade by turning the T-handle in the counter-clockwise direction when the sawmill is not in use. Failure to do so will result in flat spots on the rubber belts. These flat spots will cause the mill to vibrate excessively during next use.****

Add grease to all T-handle threads on the sawmill: three (3) on the track bunks and one (1) on the log clamp assembly.




BAND WHEEL DOOR LATCHES

Using the hardware listed below, assemble the three (3) band wheel door latches.

6x	M4 X 14 mm Phillips Flat Head Screw		2x	Latch Spacer	
9x	M4 X 10 mm Phillips Flat Head Screw		3x	Latch	
15x	M4 Lock Nut				


Using a Phillips head screwdriver and a socket/wrench, install the upper latch using five (5) M4 X 10 mm Phillips flat head screws and M4 lock nuts. Install each of the bottom latches with a spacer, three (3) M4 X 14 mm Phillips flat head screws, two (2) M4 X 10 mm Phillips flat head screws, and five (5) M4 lock nuts. The longer screws pass through the three (3) holes in each of the spacers.





ROLLING THE SAWMILL HEAD ASSEMBLY


Roll the sawmill head assembly along the length of the track to ensure it moves freely. If it binds or feels tight, the carriage wheel spacing can be adjusted by adding or removing washers like was discussed at the ***beginning of this section***.



7. ENGINE

ENGINE OIL

Refer to the engine manual before using your sawmill. Please note that the engine does not contain any gasoline or engine oil when it is shipped. Furthermore, the engine is equipped with an oil alert system, meaning that if the crankcase oil level is low or empty, the power is cut to the spark plug and it will not start.




SAWMILL SET-UP PROCEDURES

BELT TENSION


Follower Belt: Polyurethane belt that seats tightly in the band wheel V-groove. No adjustment is required for this belt.

Drive Belt: To check the belt tension, using your hand firmly try to deflect the belt up and down. There should be no more than ¼" (6 mm) of deflection. If the belt deflection exceeds this amount, it will need to be tightened as described below.



****Never attempt to adjust the belt tension with the engine running. As a safety precaution, remove the spark plug cap.****


To tighten the drive belt, start by loosening the four (4) bolts that secure the engine to the engine mount.






With the engine free to slide on the engine mounting plate, turn the nut on the horizontal stud in the clockwise direction. This will pull the engine towards the stud and apply more tension on the belt. Do this step incrementally while checking the belt for proper deflection. It is also important to ensure that the engine remains perpendicular to the drive belt. Over-tightening can cause the engine to twist on the mounting plate, resulting in belt alignment issues and premature wear. Once the desired belt tension is set, tighten the 4 engine bolts.

Alternatively, if the drive belt is too tight, the nut on the horizontal stud can be turned counter-clockwise.




BLADE TRACKING


Never attempt to adjust the blade tracking with the engine running. As a safety precaution, remove the spark plug cap. It is also advised to wear gloves and safety glasses when working with the blade as it is extremely sharp.




The blade should run with the same tooth to band wheel face distance on both sides: $\frac{3}{8}$ " (9 mm) is ideal. The back of the blade will be just proud of the back of the band wheel at this distance and is a quicker check than using a tape measure. If an adjustment on either side is required, the below steps detail this procedure.



Loosen the blade guide assembly bolt using a socket/wrench. The round shaft should now be free to slide rearward and out of the way. Perform this step on both blade guide assemblies. This ensures the guide bearings will not influence tracking of the blade whilst being adjusted.




Take some tension off the blade by turning the T-handle in the counter-clockwise direction one full turn from its fully-tensioned position.




Adjusting The Driven (Right-Hand) Side


Loosen the tracking alignment locking nut with a 24 mm wrench or an adjustable wrench.




The alignment bolt can now be turned to change the angle of the band wheel and track the blade. To move the blade more rearward on the band wheel, turn this bolt clockwise. Alternatively, turning the bolt in the counter-clockwise direction will force the blade to run more forward on the band wheel. Turn the bolt $\frac{1}{2}$ turn and re-tension the blade.



Tighten the blade tension back to 25 ft•lb (34 N•m). While wearing gloves, spin the band wheel with your hand and observe how the blade tracking has changed. Measure the distance again and repeat the above step to further compensate if required. The ideal measurement is $\frac{3}{8}$ " (9 mm) or check that the back of the blade is flush with the back of the band wheel.




Once satisfied with the measurement, tighten the locking nut clockwise.







BLADE GUIDE ADJUSTMENT

Never attempt to adjust the guide blocks or the guide bearing with the engine running. As a safety precaution, remove the spark plug cap. It is also advised to confirm that the blade is tracking properly before performing the steps below. Blade tracking is covered in the **previous section**. Using a 4 mm hex key, loosen the blade guide blocks on both the left and right sides. They should be free to slide up and down.





Loosen the blade guide assembly bolt using a socket/wrench. The round shaft should now be free to slide back and forth. Position it so that there is a thick paper-sized gap (.040" or 1 mm) between the bearing and the back of blade. Tighten the bolt against the flat on the shaft to secure the assembly back into position.






Using a feeler gauge or thick piece of paper (.020" / 0.5 mm), place it between the blade and both guide blocks and then tighten the set screws.



SAWMILL MAINTENANCE

BLADE TENSION


Proper blade tension is achieved using a torque wrench with a 24 mm socket to torque the T-handle to 25 ft•lb (34 N•m). Ensure the belleville washers are oriented and installed as shown in the picture below.



CHANGING THE BLADE


Never attempt to change the blade with the engine running. As a safety precaution, remove the spark plug cap. Gloves and safety glasses must be worn when changing the blade.

Remove the tension in the blade by turning the T-handle in the counter-clockwise direction and then open the blade guard cover. The blade should now be loose and free to pull straight out the front. The new blade can now be installed, guards closed and proper blade tension set.




REPLACING BELTS


Never attempt to replace the belts with the engine running. As a safety precaution, remove the spark plug cap. Gloves and safety glasses must be worn when replacing the belts. There are two V-belts on the sawmill. It is recommended to use a BX79 cogged belt for the drive side and a Woodland Mills polyurethane follower belt.



Remove the tension in the blade by turning the T-handle in the counter-clockwise direction and then open the blade guard cover. The blade should now be loose and free to pull straight out the front.



To change the drive side belt, loosen the four bolts that secure the engine to the engine mount using wrenches.



Now that the engine is free to slide on the engine mounting plate, turn the nut on the horizontal stud in the counter-clockwise direction. This will allow the engine to move and also take the tension off of the belt. The old belt can now be removed and the new belt installed. Tension the new belt and refer to the **BELT TENSION** instructions described in the **SAWMILL SET-UP PROCEDURES** section of the manual.

The follower belt is changed by prying it off and installing the new one with the aid of slotted screw drivers. The blade can now be re-installed, guards closed, and proper blade tension set.

****Note that blade tracking is likely to change and need adjusting when new belts are installed. Refer to BLADE TRACKING for more information.****




TROUBLESHOOTING

Problem/Issue	Possible Causes	Resolution Options
Producing wavy cuts	<ol style="list-style-type: none"> 1. Inadequate blade tension. 2. Improper blade guide set up. 3. Improper blade tracking. 4. Sap build up on blade. 5. Dull blade. 6. Pushing mill too quickly. 	<ol style="list-style-type: none"> 1. Tighten blade. Refer to page 57. 2. Gap between guide blocks and blade are incorrect. Refer to page 55. 3. Adjust blade tracking. Refer to page 51. 4. Install new blade. Refer to page 57. Always use blade lubricant. 5. Install new blade. Refer to page 57. 6. Slow feed rate down and push head slower through log.
Last board is tapered or narrow in middle	<ol style="list-style-type: none"> 1. Tracks are not level. 	<ol style="list-style-type: none"> 1. Tracks need to be checked with level and adjusted to be square. They also need to be set up on firm, sturdy base so deflection does not occur from logs or sawmill head.
Blade dulls quickly	<ol style="list-style-type: none"> 1. Logs are not clean. 2. Foreign objects in log. 	<ol style="list-style-type: none"> 1. Logs may contain dirt/sand causing blades to wear prematurely. 2. Tree may contain nails, staples, old fencing etc.
Blade comes off band wheels	<ol style="list-style-type: none"> 1. Inadequate blade tension. 2. Improper blade guide set up. 3. Improper blade tracking. 4. Belts are worn. 5. Dull blade. 6. Pushing mill too quickly. 	<ol style="list-style-type: none"> 1. Tighten blade. Refer to page 57. 2. Gap between guide blocks and blade are incorrect. Refer to page 55. 3. Adjust blade tracking. Refer to page 51. 4. Install new belts. Refer to page 58. 5. Install new blade. Refer to page 57. 6. Slow feed rate down and push head slower through log.
Blades are breaking	<ol style="list-style-type: none"> 1. Too many blade sharpenings. 2. Inadequate blade tension. 3. Improper blade guide set up. 4. Improper blade tracking. 5. Pushing mill too quickly. 	<ol style="list-style-type: none"> 1. Replace blade. Refer to page 57. 2. Binding between guide blocks when blade is too loose. Tighten blade. Refer to page 57. 3. Gap between guide blocks and blade are incorrect. Refer to page 55. 4. Adjust blade tracking. Refer to page 51. 5. Slow feed rate down and push head slower through log.
Blade is slowing down or stopping when milling	<ol style="list-style-type: none"> 1. Inadequate blade tension. 2. Improper drive belt tension. 3. Pushing mill too quickly. 	<ol style="list-style-type: none"> 1. Tighten blade. Refer to page 57. 2. Belts are worn or too loose. Replace. Refer to page 58. 3. Slow feed rate down and push head slower through log.
Mill is not cutting or cutting very slowly	<ol style="list-style-type: none"> 1. Dull blade. 2. Blade is on backwards. 	<ol style="list-style-type: none"> 1. Install new blade. Refer to page 57. 2. Remove blade and flip it inside out. The teeth should be facing in the direction of the log supports.
Mill is vibrating excessively	<ol style="list-style-type: none"> 1. Log is not clamped securely. 2. Belts are deformed. 3. Band wheel bearing issue. 4. Pushing mill too quickly. 5. Loose bolts. 	<ol style="list-style-type: none"> 1. Ensure log is clamped firmly resting on log bunks and against log supports. 2. Belts may have flats in them from leaving blade tension tight when not in use. Replace them. Refer to page 58. 3. Inspect and replace the band wheel bearings if worn. 4. Slow feed rate down when milling. 5. Check all bolts to ensure they are tight.

REPLACEMENT PARTS ORDERING

When ordering replacement parts, first locate the balloon number(s) from the appropriate **exploded assembly view** as shown in the example below:



Next, turn to the **Parts List** section and locate the balloon number in the “**Item**” column:

PARTS LIST

Item	Quantity		Part No.	Description
	14 hp	9.5 hp		
1	4	4	0001073	TRACK RAIL, 58.5 mm TALL
2	2	2	0001075	LOG BUNK, END
3	2	2	0001080	LOG BUNK, MID
4	1	1	0001084	LOG BUNK, CENTER
5	2	2	0001072	REINFORCEMENT PLATE, 90 X 200 mm
6	12	12	0001071	LEVELLING FOOT BASE
7	4	4	0001055	CARRIAGE STOP
8	1	1	0001062	LOG CLAMP SHAFT AND BRACKET WELDMENT

Record the part number (e.g. 0001071, HHB-MBM080FCJ, etc.) in the “**Part No.**” column.

Contact Woodland Mills through the website (or via phone/email) and provide the list of part numbers, including quantities for each item.



PARTS LIST

Highlighted rows are items specific to HM126-14 (14 Horsepower) sawmill.

Item	Quantity		Part No.	Description
	14 hp	9.5 hp		
1	4	4	0001073	TRACK RAIL, 100 X 58.5 mm, 1950 mm LG
2	2	2	0001075	LOG BUNK, END
3	2	2	0001080	LOG BUNK, MID
4	1	1	0001084	LOG BUNK, CENTER
5	2	2	0001072	REINFORCEMENT PLATE, 90 X 200 mm
6	12	12	0001071	LEVELLING FOOT BASE
7	4	4	0001055	CARRIAGE STOP
8	1	1	0001062	SHAFT WELDMENT, QUICK-LOCK LOG CLAMP
9	1	1	0001069	MOUNTING BRACKET, QUICK-LOCK LOG CLAMP
10	1	1	0001061	RECEIVER, QUICK-LOCK LOG CLAMP
11	1	1	0001211	QUICK-LOCK LOG CLAMP
12	4	4	0001059	T-BOLT, M10 X 1.5, 40 mm LG
13	2	2	0001056	LOG SUPPORT, BEVELLED, 450 mm LG
14	2	2	0001465	LOG SUPPORT, KEY STOP, 190 mm LG
15	1	1	0001634	BACK BEAM
16	2	2	0001127	POST SLEEVE
17	4	4	0001125	POST SLEEVE BUSHING, 50 X 50 mm POST
18	4	4	0001126	POST SLEEVE LOCKING PLATE, 50 X 50 mm POST
19	1	1	0001020	LUBRICATION TUBING BRACKET, FLAT
20	1	1	0001025	TENSION ROD, TR18X3 THD, 175 mm LG
21	1	1	0001034	SPRING WASHER HOLDER, 120 X 50 mm, 25 mm LG TUBE
22	12	12	0006088	BELLEVILLE WASHER, 20.4 ID, 40 OD, 2.5 THK, 3.45 mm TALL, 2111 lb WORKING LOAD
23	2	2	0001046	SPACER, 42 OD X 20 ID X 5 mm THK
24	1	1	0001029	TENSION HANDLE, 220 mm LG
25	2	2	0001030	HANDLE GRIP, GROOVED, 26 mm ID, 108 mm LG
26	1	1	0001128	BELT TENSIONER SCREW PLATE
27	2	2	0001093	GUIDE BLOCK HOLDER
28	1	1	0001096	GUIDE BLOCK HOLDER SHAFT, BLADE STOPPER
29	1	1	0001095	SAW BLADE STOPPER, 67.5 mm LG
30	1	1	0001091	GUIDE BLOCK HOLDER SHAFT, DRIP NOZZLE
31	1	1	0001092	DRIP NOZZLE, 6 mm DIA
32	4	4	0001090	GUIDE BLOCK
33	1	1	0001635	BAND WHEEL HOUSING
34	1	1	0001637	BAND WHEEL DOOR, LEFT
35	1	1	0001639	BAND WHEEL DOOR, RIGHT
36	4	4	0001097	HINGE PIN, 7 mm DIA, 68 mm USEABLE LG
37	2	2	0001001	DOOR LATCH SPACER
38	3	3	0001656	ADJUSTABLE DRAW LATCH, PADLOCKABLE
39	2	2	0001659	KNOB, MULTI-LOBE, 48 mm OD, M8 X 1.25, 17 mm LG
40	1	1	0001104	DRIVE SHAFT, 30 mm SQ, 125 mm LG, 25 mm DIA
41	1	1	0001108	FOLLOWER SHAFT, 30 mm SQ, 216.5 mm LG, 25 mm DIA
42	1	1	0001782	BLADE TRACKING ADJUSTMENT BOLT, M16 X 2, 100 mm LG, TAPERED



Item	Quantity		Part No.	Description
	14 hp	9.5 hp		
43	2	2	0001105	BAND WHEEL, 19 in
44	2	2	0004820	RETAINING RING, INTERNAL, 62 mm BORE (65 mm GROOVE)
45	1	1	0001107	V-BELT, FOLLOWER, B1448Li, 19 in DIA
46	1	1	0001045	IDLER PULLEY SHAFT, 16 mm DIA, 130 mm LG, M16 X 2 THD
47	1	1	0001047	IDLER PULLEY, DUAL BEARING, 37 mm WD, 80 mm DIA
48	1	1	0004816	RETAINING RING, INTERNAL, 40 mm BORE (42.5 mm GROOVE)
49	1	1	0004798	RETAINING RING, EXTERNAL, 17 mm SHAFT (16.2 mm GROOVE)
50	1	1	0001626	V-BELT, COGGED, BX79
51	1	1	0001123	SAW BLADE, 7/8 in PITCH, 165 TEETH, 1-1/4 WD X 144 LG X .042 in THK
52	1	1	0001655	MANUAL TUBE
53	2	2	0001135	FRONT POST, 50 X 50 mm, 1315 mm LG
54	2	2	0001660	PLASTIC END CAP, SQ, 50 X 50 mm
55	1	1	0001109	BACK POST, 50 X 50 mm, LEFT
56	1	1	0001150	BACK POST, 50 X 50 mm, RIGHT
57	4	4	0001143	CARRIAGE SIDE PLATE
58	4	4	0001037	CARRIAGE WHEEL
59	4	4	0001101	SPACER, 20 ID X 33.5 OD X 50 mm LG
60	2	2	0001102	SPACER, 13 ID X 33.5 OD X 50 mm LG
61	4	4	0001019	WHEEL SWEEPER INNER BRACKET
62	4	4	0001017	WHEEL SWEEPER OUTER BRACKET
63	4	4	0001018	WHEEL SWEEPER CABLE
64	1	1	0001139	CROSS BEAM
65	2	2	0001661	PLASTIC END CAP, RECT, 100 X 50 mm
66	1	1	0001433	LUBRICATION TUBING BRACKET, BENT
67	1	1	0001138	DASHBOARD
68	1	1	0001658	VALVE, ON/OFF, M20 X M20, 6 mm TUBE FTG
69	1	1	0001124	PUSH HANDLE
70	1	1	0001021	THROTTLE HANDLE
71	1	1	0001024	THROTTLE HANDLE CABLE MOUNT, LEFT
72	1	1	0001621	THROTTLE CABLE
73	1	1	0001111	THROTTLE CABLE STOP BUSHING
74	1	1	0001112	THROTTLE CABLE BARREL CLAMP
75	1	1	0001122	SCALE SUPPORT
76	1	1	0001038	SCALE SUPPORT SPACER PLATE
77	1	1	0001042	LOG SCALE MOUNTING BRACKET
78	1	1	0001044	SCALE INDICATOR SIGHT BRACKET
79	1	1	0001041	SCALE INDICATOR SIGHT
80	1	1	0001129	MAGNETIC SCALE, 24 in, YELLOW
81	1	1	0001835	MAGNETIC SCALE, 24 in, WHITE
82	1	1	0001217	CLUTCH SPACER, 27 ID X 50.5 OD X 30 mm LG
83	1	1	0001137	PARALLEL KEY, 1/4 X 1/4 in, 1 in LG
84	1	-	0001824	CLUTCH ASSEMBLY, 1 in [25.4 mm] SHAFT, 108 mm DIA PULLEY
85	-	1	0001823	CLUTCH ASSEMBLY, 1 in [25.4 mm] SHAFT, 87 mm DIA PULLEY
86	1	1	0001814	CLUTCH HOUSING GUARD, SIDE FLANGES, 123 mm DIA
87	1	1	0001133	LUBRICANT TANK, 10 L [2.6 gal]
88	1	1	0001132	TANK CAP
89	1	1	0005221	BEAD CHAIN, 3 mm BEAD, 140 mm LG
90	1	1	0001622	LUBRICANT LINE, VALVE-TO-TANK




Item	Quantity		Part No.	Description
	14 hp	9.5 hp		
91	1	1	0001623	LUBRICANT LINE, VALVE-TO-BLADE
92	1	1	0001120	LIFT MECHANISM HOUSING
93	1	1	0001121	LIFT MECHANISM EXTENSION ARM
94	2	2	0001100	LIFT CABLE HOOK
95	1	1	0001048	BRONZE NUT, LH TR20X4 FEM THD, M27 X 1.5 MALE THD
96	1	1	0001134	LEAD SCREW, LH TR20X4 X 335 mm LG THD
97	2	2	0006079	SLOTTED NUT, ROUND, M14 X 1.5
98	1	1	0001039	CRANK HANDLE INDEX PLATE, 178 mm DIA
99	1	1	0001086	CRANK HANDLE ARM WELDMENT
100	1	1	0004777	SPRING PIN, SLOTTED, 5 mm DIA, 20 mm LG
101	1	1	0001657	INDEX PLUNGER, M20 X 1.5
102	1	1	0001085	HANDLE, TAPERED, 32 mm DIA, 105 mm LG, M12 THRU
103	7	7	0001099	WIRE ROPE PULLEY, 6001-2RS BEARING, 73 mm DIA
104	7	7	0004813	RETAINING RING, INTERNAL, 28 mm BORE (29.4 mm GROOVE)
105	6	6	0004953	SPACER, 13 ID X 18 OD X 12 mm LG
106	2	2	0004952	SPACER, 13 ID X 18 OD X 5 mm LG
107	1	1	0001624	LIFT CABLE A, 4 mm DIA
108	1	1	0001625	LIFT CABLE B, 4 mm DIA
109	1	1	0001136	EXHAUST REDIRECT, 9.5 & 14 hp KOHLER ENGINES
110	1	-	CH440-3149	ENGINE, KOHLER COMMAND PRO HORIZONTAL, 14 hp
111	-	1	CH395-3149	ENGINE, KOHLER COMMAND PRO HORIZONTAL, 9.5 hp
112	1	1	SLS-03-08	FLOW CONTROL VALVE, RA, 3/8 NPT, 8 mm QUICK-CONNECT TUBE
113	4	4	5204-2RS	BALL BEARING, SEALED, ANG-CONT, DOUBLE ROW, 20 mm SFT, 47 mm HSG, 20.6 mm WD
114	2	2	6000-2RS	BALL BEARING, SEALED, 10 mm SFT, 26 mm HSG, 8 mm WD
115	7	7	6001-2RS	BALL BEARING, SEALED, 12 mm SFT, 28 mm HSG, 8 mm WD
116	2	2	6203-2RS	BALL BEARING, SEALED, 17 mm SFT, 40 mm HSG, 12 mm WD
117	4	4	6305-2RS	BALL BEARING, SEALED, 25 mm SFT, 62 mm HSG, 17 mm WD
118	2	2	51102	THRUST BEARING, SINGLE DIR, 15 mm SFT, 28 mm HSG, 9 mm WD
119	1	1	51204	THRUST BEARING, SINGLE DIR, W/ HSG, 20 mm SFT, 40 mm HSG, 14 mm WD
120	2	2	HHB-MBE075FCJ	HEX HEAD BOLT, CLS 8.8, M6 X 1, 20 mm LG, FULL
121	2	2	HHB-MBE077FCJ	HEX HEAD BOLT, CLS 8.8, M6 X 1, 22 mm LG, FULL
122	2	2	HHB-MBE085FCJ	HEX HEAD BOLT, CLS 8.8, M6 X 1, 30 mm LG, FULL
123	4	4	HHB-MBE090FCJ	HEX HEAD BOLT, CLS 8.8, M6 X 1, 35 mm LG, FULL
124	1	1	HHB-MBE105FCJ	HEX HEAD BOLT, CLS 8.8, M6 X 1, 50 mm LG, FULL
125	1	1	HHB-MBE110PCJ	HEX HEAD BOLT, CLS 8.8, M6 X 1, 55 mm LG, 18 mm LG THD
126	2	2	HHB-MBJ063FCJ	HEX HEAD BOLT, CLS 8.8, M8 X 1.25, 12 mm LG, FULL
127	31	31	HHB-MBJ075FCJ	HEX HEAD BOLT, CLS 8.8, M8 X 1.25, 20 mm LG, FULL
128	2	2	HHB-MBJ090FCJ	HEX HEAD BOLT, CLS 8.8, M8 X 1.25, 35 mm LG, FULL
129	6	6	HHB-MBM075FCJ	HEX HEAD BOLT, CLS 8.8, M10 X 1.5, 20 mm LG, FULL
130	9	9	HHB-MBM080FCJ	HEX HEAD BOLT, CLS 8.8, M10 X 1.5, 25 mm LG, FULL
131	2	2	HHB-MBM095FCJ	HEX HEAD BOLT, CLS 8.8, M10 X 1.5, 40 mm LG, FULL
132	4	4	HHB-MBM110PCJ	HEX HEAD BOLT, CLS 8.8, M10 X 1.5, 55 mm LG, 26 mm LG THD
133	2	2	HHB-MBR100FCJ	HEX HEAD BOLT, CLS 8.8, M12 X 1.75, 45 mm LG, FULL
134	1	1	HHB-MBR120PCJ	HEX HEAD BOLT, CLS 8.8, M12 X 1.75, 65 mm LG, 30 mm LG THD
135	5	5	HHB-MBR125PCJ	HEX HEAD BOLT, CLS 8.8, M12 X 1.75, 70 mm LG, 30 mm LG THD
136	16	16	HHB-MBR135PCJ	HEX HEAD BOLT, CLS 8.8, M12 X 1.75, 80 mm LG, 30 mm LG THD
137	7	7	HHB-MBR145PCJ	HEX HEAD BOLT, CLS 8.8, M12 X 1.75, 90 mm LG, 30 mm LG THD




Item	Quantity		Part No.	Description
	14 hp	9.5 hp		
138	2	2	HHB-MBR155PCJ	HEX HEAD BOLT, CLS 8.8, M12 X 1.75, 100 mm LG, 30 mm LG THD
139	2	2	HHB-MBR165FCJ	HEX HEAD BOLT, CLS 8.8, M12 X 1.75, 110 mm LG, FULL
140	1	1	HHB-MBR175PCJ	HEX HEAD BOLT, CLS 8.8, M12 X 1.75, 120 mm LG, 30 mm LG THD
141	1	1	HHB-MBR195PCJ	HEX HEAD BOLT, CLS 8.8, M12 X 1.75, 140 mm LG, 30 mm LG THD
142	12	12	HHB-MCA175FCJ	HEX HEAD BOLT, CLS 8.8, M16 X 2, 120 mm LG, FULL
143	4	4	HHB-MCF175PCJ	HEX HEAD BOLT, CLS 8.8, M20 X 2.5, 120 mm LG, 46 mm LG THD
144	2	2	HHB-UBU015FGE	HEX HEAD BOLT, GR 5, 3/8-16, 5/8 in LG, FULL
145	1	-	HHB-UBV025FGJ	HEX HEAD BOLT, GR 8, 3/8-24, 1-1/4 in LG, FULL
146	-	1	HHB-UCA025FGJ	HEX HEAD BOLT, GR 8, 7/16-20, 1-1/4 in LG, FULL
147	34	34	FHH-MBM080FCM	HEX BOLT, FLANGED, CLS 10.9, M10 X 1.5, 25 mm LG, FULL
148	16	16	FHH-MBM090PCM	HEX BOLT, FLANGED, CLS 10.9, M10 X 1.5, 35 mm LG, 26 mm LG THD
149	2	2	SHC-MBM080FCP	SHCS, CLS 12.9, M10 X 1.5, 25 mm LG, FULL
150	9	9	PFH-MAW059FCM	SCREW, PFH, CLS 10.9, M4 X 0.7, 10 mm LG, FULL
151	1	1	PPH-MAW063FTA	SCREW, PPH, SST, M4 X 0.7, 12 mm LG, FULL
152	6	6	PFH-MAW067FCM	SCREW, PFH, CLS 10.9, M4 X 0.7, 14 mm LG, FULL
153	2	2	PST-UBC015FAJ	SCREW, PPH, ST, NO. 10, 5/8 in LG
154	2	2	FTS-MBE055TA	SET SCREW, FLAT TIP, SST, M6 X 1, 8 mm LG
155	8	8	FTS-MBJ055TA	SET SCREW, FLAT TIP, SST, M8 X 1.25, 8 mm LG
156	14	14	FTW-MBE000AJ	FLAT WASHER, M6
157	17	17	FTW-MBJ000AJ	FLAT WASHER, M8
158	8	8	FTW-MBM000AJ	FLAT WASHER, M10
159	63	63	FTW-MBR000AJ	FLAT WASHER, M12
160	16	16	FTW-MCF000AJ	FLAT WASHER, M20
161	10	9	FDW-MBM083000AJ	FENDER WASHER, M10, 34 mm OD
162	2	3	FDW-MBR086000AJ	FENDER WASHER, M12, 37 mm OD
163	2	2	SLW-MBEAJ	SPLIT LOCK WASHER, M6
164	5	4	SLW-MBMAJ	SPLIT LOCK WASHER, M10
165	1	2	SLW-MBRAJ	SPLIT LOCK WASHER, M12
166	6	6	HXN-MBECH	HEX NUT, CLS 8, M6 X 1
167	2	2	HXN-MBJCH	HEX NUT, CLS 8, M8 X 1.25
168	6	6	HXN-MBMCH	HEX NUT, CLS 8, M10 X 1.5
169	6	6	HXN-MBRCH	HEX NUT, CLS 8, M12 X 1.75
170	37	37	HXN-MCACH	HEX NUT, CLS 8, M16 X 2
171	1	1	THN-MCHCC	HEX NUT, THIN, CLS 4, M20 X 1.5
172	4	4	FHN-MBMCH	HEX NUT, FLANGED, CLS 8, M10 X 1.5
173	15	15	HLN-MAWCH	LOCK NUT, CLS 8, M4 X 0.7
174	8	8	HLN-MBECH	LOCK NUT, CLS 8, M6 X 1
175	16	16	HLN-MBJCH	LOCK NUT, CLS 8, M8 X 1.25
176	20	20	HLN-MBMCH	LOCK NUT, CLS 8, M10 X 1.5
177	33	33	HLN-MBRCH	LOCK NUT, CLS 8, M12 X 1.75
178	1	1	HLN-MCACH	LOCK NUT, CLS 8, M16 X 2
179	4	4	HLN-MCFCH	LOCK NUT, CLS 8, M20 X 2.5
180	44	44	FLN-MBMCL	LOCK NUT, FLANGED, CLS 10, M10 X 1.5

EXPLODED ASSEMBLY VIEWS




SAW HEAD






BACK BEAM






GUIDE BLOCK HOLDERS




Drip Nozzle



Blade Stopper




BAND WHEEL HOUSING






BAND WHEEL HOUSING DOORS



This exploded view diagram illustrates the assembly of a steering wheel. The main components shown are two steering wheels (43), a central hub (41), and various mounting hardware. The wheels feature a five-spoke design with the text "WOODLAND HILLS" on the spokes. The assembly process involves mounting the wheels onto the hub using a series of washers (117, 116, 116, 116), spacers (46, 47), and nuts (178). The diagram also shows the installation of the hub into the vehicle's frame using a bracket (40) and a nut (178). The exploded view shows the components in their relative positions for assembly.




ENGINE COMPONENTS—14 hp






ENGINE COMPONENTS—9.5 hp




This diagram is a detailed exploded view of a mechanical assembly, likely a piece of industrial equipment. It shows the main frame, a large rotating drum or cylinder, and various support structures and components. The assembly is composed of numerous parts, each identified by a circled number. Key components include a large horizontal beam (53), a vertical support (54), a large drum (112), and various rollers and guides (e.g., 103, 104, 105, 115, 137, 159, 177). The diagram uses dashed lines to indicate the assembly path and alignment of the parts. Quantity indicators (e.g., 2X, 3X, 4X, 6X, 7X, 8X) are placed next to many of the callouts to specify the number of each part required for the assembly.



CARRIAGE LEG, WHEEL, AND SWEEPER





LIFT MECHANISM






THROTTLE HANDLE





TUBING & CABLES





NOTES

Lined area for notes, consisting of 25 horizontal lines.

This page intentionally left blank.



DISCOVER THE WOODLAND™