


# MULTILANDER™ ACCESSORY

\*Lumber not included.



## UNIVERSAL MOUNTING KIT OPERATOR'S MANUAL



Multilander™ is a trademark of Woodland Mills, Inc.

This page intentionally left blank.



## TABLE OF CONTENTS

<b>TABLE OF CONTENTS</b>	<b>1</b>
<b>CONFIGURATIONS &amp; ACCESSORIES</b>	<b>2</b>
<b>INTRODUCTION</b>	<b>3</b>
<b>ASSEMBLY</b>	<b>3</b>
1. TOOLS REQUIRED	3
2. FLATBED EXAMPLE	3
3. FRONT YOKE AND REAR SUPPORTS	5
4. FLATBED TO TRAILER	7
<b>ADDITIONAL KITS</b>	<b>9</b>
<b>PARTS LIST &amp; EXPLODED VIEW</b>	<b>10</b>
<b>NOTES</b>	<b>11</b>

## CONFIGURATIONS & ACCESSORIES

The Multilander Logging Trailer is available in five (5) configurations shown below. Each configuration can be further customized with additional accessories such as a cant hook mount, a ball mount hitch kit, and a universal mounting kit. Contact Woodland Mills or visit [our website](#) for information and pricing.



1. LOGGING TRAILER



2. LOGGING TRAILER  
WITH UTILITY BOX



3. LOGGING TRAILER  
WITH UTILITY DUMP BOX



4. PRO LOGGING TRAILER



5. PRO LOGGING TRAILER  
WITH UTILITY DUMP BOX






## INTRODUCTION

The Multilander™ Universal Mounting Kit, while on a basic level consists of just three (3) mounting brackets with hardware, provides users a base on which a multitude of custom trailer configurations can be created. Examples include flatbed trailers, water storage transporters, and hay wagons to name a few.

## ASSEMBLY

### 1. TOOLS REQUIRED

Tool	Specification
Wrench/Socket	18 mm
Wrench/Socket	19 mm
Adjustable Wrench	Variable




### 2. FLATBED EXAMPLE

On the next page is a dimensioned drawing of a 4x8 ft [1.2x2.4 m] flatbed example made from 2x6 in [38x140 mm] dimensional lumber. \*\*Note that the lumber and any related hardware must be supplied by the customer.\*\*





Qty	Description
4	2x6x96 in [38x140x2438 mm] Lumber
17	2x6x48 in [38x140x1219 mm] Lumber
68	No. 10 Wood Screw, 3 in [76 mm] Long
34	No. 8 Wood Screw, 2-½ in [64 mm] Long

The overall design of the flatbed is up to the customer. Only the circled mounting location dimensions need be adhered to—the rest of the design can be customized as desired.




### 3. FRONT YOKE AND REAR SUPPORTS



Assemble the front yoke and rear hinge supports to the flatbed using the hardware listed below.

8x	M12 X 70 mm Flanged Hex Bolt		1x	Front Yoke	
8x	M12 Flanged Lock Nut		2x	Rear Hinge Support	

Slide the front yoke and two (2) rear hinge supports over the joists as shown below. Align the holes in the supports with the pre-drilled joist holes.





Securely fasten the yoke and supports to the joists using eight (8) M12 X 70 mm bolts and M12 lock nuts—four (4) in front yoke and two (2) in each rear hinge support.




## 4. FLATBED TO TRAILER


Use the components listed in the table below to secure the assembled flatbed to the trailer.

1x	Bent Clevis Pin		1x	Linch Pin	
----	-----------------	---	----	-----------	---

Remove the linch pins and hinge pins from the trailer's rear log rack.






Install the flatbed assembly to the trailer. Secure the rear flatbed supports with the trailer hinge pins and linch pins. Rest the front yoke on the trailer chassis beam.







Install the bent clevis pin through one side of the front yoke, under the trailer chassis, and then through the other side of the yoke. Secure the clevis pin with the linch pin.






## ADDITIONAL KITS

To enhance the potential of the Universal Mounting Kit, the front yoke was designed with an integral hook bar allowing for lift capability with the addition of the Boom & Winch Kits. Contact Woodland Mills or visit [\*\*\*our website\*\*\*](#) for more information.



## PARTS LIST & EXPLODED VIEW

Item	Qty	Part No.	Description
1	1	0002399	FRONT YOKE
2	2	0002402	REAR HINGE SUPPORT
3	1	0002400	BENT-PULL CLEVIS PIN, 12 mm DIA, 105 mm USEABLE LG
4	1	HDW	LINCH PIN, 3/16 in DIA, 1 in USEABLE LG
5	8	HDW	HEX BOLT, FLANGED, M12 X 1.75, 70 mm LG, 30 mm LG THD
6	8	HDW	LOCK NUT, FLANGED, M12 X 1.75



## This image shows a single sheet of white paper with horizontal blue ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



Lined area for notes or additional information, consisting of 20 horizontal lines.

This page intentionally left blank.

